



Shark Lift-Away Professional Steam Pocket Mop Handle Replacement

Attach and remove the handle from the main compartment for easy storage.

Written By: Nancy K Do



INTRODUCTION

If the handle for your Steam Pocket Mop gets loose and falls off, or if you would like to remove the handle for easy storage, use this guide to walk you through the process. You will need a Phillips #2 screwdriver for this replacement.

TOOLS:

- Phillips #2 Screwdriver (1)

Step 1 — Mop Handle



- Turn off the Steam Pocket Mop and unplug it from the wall.

 Be sure that any water in the water tank cools before proceeding.

Step 2



- Place the Steam Pocket Mop face down on a flat surface.
-  Take note of the placement of the handle; the side labelled "front" should face forward.

Step 3



- Remove the screw located underneath the cord holder.
- Turn the screwdriver counter-clockwise to loosen the screw from its slot.

(i) This is a long screw and will take time to remove.

To disassemble your device, follow these instructions in reverse order.