



Shark Rocket Powerhead AH401 Dust Cup Replacement

This guide will demonstrate how to replace a broken or cracked Dust Cup on a Shark Rocket Powerhead AH401

Written By: Toan Pham



INTRODUCTION

Replacing the Dust Cup is an easy replacement that requires no tools. This guide demonstrates how to replace the Dust Cup if it needs to be cleaned or has become broken.

Step 1 — Dust Cup



 Ensure the device is turned off and unplugged from any power source before beginning work.

- Push down on the dust can lever to release the dust can in order to get to the filter grill.

Step 2



- Remove the dust cup by lifting it off the dock.

To reassemble your device, follow these instructions in reverse order.