



Sharp Aquos LC13B2UA Stand Replacement

How to replace a Sharp Aquos LC13B2UA stand.

Written By: Robert Hobson



 **TOOLS:**

- Phillips #2 Screwdriver (1)

Step 1 — Stand



- Place the TV face down on a flat smooth surface as to not scratch the screen.
- Using a Phillips #2 screwdriver remove the four 8mm screws attaching the stand to the TV.

Step 2



- Lift the stand off the television.

To reassemble your device, follow these instructions in reverse order.