



# Sharp LC-37SB24U Television CCFL Replacement

This video guide demonstrates disassembling the entire system to replace a lamp (CCFL). Also shown are removing the inverter, power supply and main board.

Written By: Steve Baker



This document was generated on 2019-10-02 11:20:27 PM (MST).

## INTRODUCTION

This video guide demonstrates disassembling the entire system to replace a lamp (CCFL). Also shown are removing the inverter, power supply and main board.

Always disconnect the power several minutes prior to working on a television to avoid risk of shock. Also use caution with CCFLs, they contain mercury.

This unit shuts off the screen after 2 seconds when a lamp failure is detected.

## TOOLS:

- [Mahi Driver Kit - 48 Bit Driver Kit \(1\)](#)
- [Metal Spudger \(1\)](#)

To reassemble your device, follow these instructions in reverse order.