



Shop-Vac MC150A Power Unit Assembly Replacement

This guide will help you take out and replace the power unit assembly.

Written By: Ngunlian



INTRODUCTION

This guide will separate the power unit assembly from the vacuum.

TOOLS:

- **Screwdriver** (1)

Step 1 — Power Unit Assembly



- Separate the power unit assembly (the black top) from the tank assembly (the red bottom).
- To open, grab the black clips on both sides of the vacuum. Pull away from device and lift up black top.

Step 2



- Turn over the black top and locate the 3 screws to remove the filter section.
- Remove the 3 H3.5 Allen screws on the black top.

Step 3



- Separate top filter section from the power unit assembly.
- Remove the four H3.5 Allen screws.

Step 4



- After removing the screws, separate the power unit assembly from the cover.

To reassemble your device, follow these instructions in reverse order.