



# Sigma 24-70 Disassembly

Written By: Greg



## INTRODUCTION

1°/ Remove the 4 screws on the bottom (take care because to one, the blue screw, of them is shorter than others).

### TOOLS:

- Essential Electronics Toolkit (1)

## Step 1 — Sigma 24-70 Disassembly



- 1°/ Remove the 4 screws at the bottom (take care because to one of them, blue screw, is shorter than the others)

## Step 2



- Remove the 4 screws around the steel ring in order to disassemble the captor (blue area) and the plastic ring (red area) which is insert inside the steel ring and behind the captor

## Step 3



- Remove the steel ring (red area) due to a vertical translation (take care with the vertical sheet, in green area metal, which is used to open the diaphragm)

To reassemble your device, follow these instructions in reverse order.