



SilverCrest KH2311 micro system Hi-Fi (2010)

Teardown

This sound device was sell by the shops Lidl in Europe. The original (chinese) manufacturer name is unknown.

Written By: David D.



This document was generated on 2020-04-04 02:30:57 AM (MST).

 **TOOLS:**

- Phillips #1 Screwdriver (1)

Step 1 — SilverCrest KH2311 micro system Hi-Fi (2010) Teardown




- This is the front side of the SilverCrest KH2311. There is nothing to do there.

Step 2



- Remove the 2 screws of the ON/OFF button.

Step 3




- Back : 2 screws on the sound outputs connectors, and 2 screws on the top (on this picture it is on the right side).

Step 4



- Remove 2 screws from the 2 sides of the sound device.

Step 5





- Bottom : Unpaste 2 squares (those on the front side of the device), then remove the 2 screws.

Step 6



- Pull slowly the CD part on the right, and the other part to the left. There is 2 pictures to show you how that can move.
- Note: there is still a cable (soldered) between the the power (left part) and the power adapter (right side).

Step 7



- Views of the inside (note: the cable to the electrical power has been cut).