



# Skytex SP728 Case Replacement

This guide will show users how to replace the back case of the device.

Written By: Michelle Strickland



# INTRODUCTION

How to remove the back case of the tablet.

## TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #00 Screwdriver](#) (1)

## Step 1 — Case



- Make sure the device is powered off
- Rotate the device so the ports and screws face you

## Step 2



- Using a small phillips screwdriver, unscrew both end screws

## Step 3



- Using a plastic opening tool, work your way around the edge of the device, separating the case from the rest of the device

## Step 4



- Once the case has been loosened, pry the backing off gently with your hands.

 Make sure to remove the case gently as extra force can break the clasps or the case itself.

To reassemble your device with a new case, follow these instructions in reverse order.