



SodaStream Fountain Jet A200 Washer Replacement

In this guide, an extra washer will be removed or, a worn out washer will be replaced with a new one.

Written By: Katie Fetters



INTRODUCTION

This guide is to instruct a person on how to remove a worn out washer or remove an extra washer that may have been installed during manufacturing.



TOOLS:

- [Tweezers](#) (1)
-

Step 1 — Remove the CO2 tank



- With one hand, press in the two gray oval shaped buttons found on either side.
- Gently pull back on the cover until it releases from the device.
- Remove the back cover of the device.


Step 2



- Grasp the CO2 tank and twist it in a clockwise motion.
- Once the CO2 tank is free, pull it towards you and lift upwards to remove it from the device.

Step 3 — removing washers



- Flip the device upside down.
 - Locate the washer, this will be in the valve where the CO2 tank was located.
 - Using tweezers, remove the old/ extra wash and insert a new washer if needed.
-  For your machine to function properly, there should only be one washer present.

To reassemble your device, follow these instructions in reverse order.