



# Sony Betamovie BMC-220 Battery Replacement

This guide gives instructions for replacing the battery on a Sony Betamovie BMC-220.

Written By: Jordan Bates



## INTRODUCTION

If your Sony Betamovie BMC-220 fails to power on as a result of a dead battery, use this guide to learn how to replace the battery in your Betamovie.

## Step 1 — Battery



- Orient your Betamovie so that the back of the device is sitting flat, and the bottom of the device is facing you.
- Slide the RELEASE switch up to bring the hand grip down.

## Step 2



- Turn the BATTERY knob to OPEN, and open the lid.
- Reminder: When inserting a new battery, make sure the knob is turned to OPEN.
- Be careful not to point the hand grip down when turning the BATTERY knob. The battery pack may fall out.

## Step 3



- Remove the battery from the Betamovie.

To reassemble your device, follow these instructions in reverse order.