




Sony Clie PEG-SL10 Battery Harness Replacement

This guide will show you how to replace a faulty battery case with a new one.

Written By: Emily



 **TOOLS:**

- Phillips #0 Screwdriver (1)

 **PARTS:**


- Battery Harness (1)

Step 1 — Battery Harness




- Remove the six screws holding the outside case of the Sony Clie.

Step 2




- Remove the six screws holding the outer case.

Step 3




- Remove the two screws holding the battery harness in place.

Step 4



- Gently pull the power cable from the socket.

Step 5



- The battery harness is now removed. Install the new harness in reverse order.

To reassemble your device, follow these instructions in reverse order.