




Sony ICFC1T Battery Replacement

Instruction on how to replace the battery for your alarm clock. You will need a CR2032 battery, it should only take about 2-5 minutes to replace.

Written By: Anna Graetz



INTRODUCTION


This guide will give step by step instructions on how to replace your battery.



PARTS:

- [CR2032 Lithium Battery](#) (1)

Step 1 — Battery



- Remove the battery compartment from the underside of the device.
- With your thumb and index finger, pinch the tab and pull gently until the compartment is released.

⚠ Always ensure that the device is unplugged before tampering with it to ensure there is no risk of electrical shock.

Step 2



- Take out old battery by pressing from the side marked "**PUSH**" on the compartment, and replace with a new battery, positive side up.

Step 3



- Replace the battery compartment into the bottom of the device.
- Reset the time of the clock.
- *(i)* Plug your clock back in as to not rely on the back up battery.

To reassemble your device, follow these instructions in reverse order.