



Sony VAIO PCG-61611L Battery Replacement

The guide will showcase how to replace the battery on the Sony VAIO PCG-61611L.

Written By: Christopher Hover



INTRODUCTION


This guide shows how to remove/replace the battery on the Sony VAIO PCG-61611L laptop computer.

Step 1 — Battery



- ⚠ Ensure that the laptop is powered off before disconnecting the battery.
- Flip the laptop over so the underside of the laptop is facing up.

Step 2



- Slide the two tabs towards each other until the battery disconnects slightly from its position.
- Carefully lift the battery out of its position away from the laptop.

(i) The battery is not pictured here, since it is missing from this particular device.

To reassemble your device, follow these instructions in reverse order.