



Sony VAIO VPC-EB33FM Battery Replacement

The purpose of this installation guide is to provide instructions on removing and installing the battery of the Sony VAIO VPC-EB33FM laptop.

Written By: Kevin



INTRODUCTION

This guide will inform readers on how to safely uninstall the battery of the Sony VAIO VPC-EB33FM laptop.



PARTS:


- [Sony VGP-BPS22 Laptop Battery \(1\)](#)

Step 1 — Battery



- If the laptop isn't turned off, then do so by holding down the power button.
- Turn the laptop onto its backside.

Step 2



- Locate the battery below the screen attachment.
- *(i)* The battery is shaped as a long rectangle with rounded edges.

Step 3



- Press into the release button while holding the unlock button in position.

Step 4



- Lift the battery out at the notch while holding the release button.

To reassemble your device, follow these instructions in reverse order.