



Sony Vaio PCG-41216L Battery Replacement

How to replace the battery in a Sony Vaio PCG-41216L.

Written By: Aaron B



INTRODUCTION

If the laptop is having internal software issues or Windows has warned that the battery has reached extremely low capacity, use this guide to remove and replace the battery.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

Step 1 — Battery



- Flip the laptop over to begin the process.

! Make sure the laptop is turned off and unplugged from the power cable.

Step 2



- Remove the two 7mm Phillips #1 screws holding the battery cover.

Step 3



- Remove the battery cover and set it aside. Carefully remove the non-functioning battery and insert the new battery in its place.
- ▣ Make sure to reattach the battery in the right position with the power port, so that the power connector lines up with the battery's port.

To reassemble your device, follow these instructions in reverse order.