



Sony Vaio PCG-51412L Battery Replacement

This guide is a step by step guide for replacing your battery.

Written By: Ian Norman



INTRODUCTION

If your laptop is not powering on or the battery is not holding a charge, you may need to replace the battery. This guide will walk you through the steps of replacing your battery, with no tools required to complete the process.



PARTS:

- [Sony VGP - BPS21A](#) (1)
-

Step 1 — Battery



- Flip your laptop so that the bottom is facing up.

Step 2



- Slide the "Lock" switch to the right.
- Slide and hold the "Release" switch to the left.

Step 3



- While holding the “Release” switch, lift the lip of the battery.
- Lift the battery up and out of the laptop.

To reassemble your device, follow these instructions in reverse order.