



# Sony Vaio PCG-61211L RAM Replacement

This guide will help replace or remove the RAM of the Sony Vaio PCG-81312L computer.

Written By: Matt Mersinger



## INTRODUCTION

In this guide, you will learn to remove and replace the RAM of a Sony Vaio PCG-81312L computer.

### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Spudger](#) (1)

*This isn't needed, but greatly recommended!*

## Step 1 — RAM




- Remove the single Phillips #00 screw from the back cover of the laptop.

## Step 2




- Lift the cover up and remove it from the computer.

## Step 3



- Identify the two RAM pieces.

## Step 4



- Push out the two outer white catch pieces holding the both sides of the RAM in position. Begin gently removing the RAM from its position.

## Step 5



- Once you have the RAM out on its own, replace it or put it back into the correct position.

To reassemble your device, follow these instructions in reverse order.