



# Sony Vaio PCG-71C11L RAM Sticks Replacement

In this guide we will be taking out and replacing the RAM Sticks.

Written By: Michael Miller




## INTRODUCTION

In this guide we will be taking out and replacing the RAM Sticks.

### TOOLS:


- [Phillips #00 Screwdriver](#) (1)

## Step 1 — RAM Sticks




- Use a Phillips #00 screwdriver to unscrew the single RAM cover screw.

## Step 2




- Pull the cover of the RAM sticks up.

## Step 3



- Pull apart the metal sides on the sides of the top RAM stick to pop it up.
- Repeat that process with the bottom RAM stick.

## Step 4



- Remove both RAM sticks.
- ⚠** Take care removing the RAM sticks as they are fragile.

Congratulations!