



Sony Vaio PCG-81114L Battery Replacement

How to replace a Sony Vaio PCG-81114L battery.

Written By: Haylie Hotte



INTRODUCTION

For this guide the only tool that will be needed is the anti-static wrist strap. This is an important tool because it prevents the device from getting ruined, static is not good for the components and parts in the laptop.

TOOLS:

- Anti-Static Wrist Strap (1)

Step 1 — Battery



- Flip the laptop over so the bottom is facing up.

Step 2



- Unlock the left tab on the battery.
- Glide the right battery tab to release the battery pack from the laptop.
- Keeping the battery tab in the released position, lift the battery up.

To reassemble your device, follow these instructions in reverse order.