



Sony Vaio PCG-81114L RAM Replacement

How to replace or upgrade Sony Vaio PCG-81114L RAM.

Written By: Haylie Hotte



INTRODUCTION



This guide will show you how simple it is to replace the RAM in the Sony Vaio PCG-81114L.

Note: It is important to use the proper tools and handle RAM with care.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

Step 1 — RAM



- Remove the 9mm Phillips #1 screw located on the back cover.
- Remove cover.
- Push out metal tabs.
- Remove card.

To reassemble your device, follow these instructions in reverse order.