




Sony Vaio PCG-81312L RAM Replacement

This guide will teach you how to remove and replace the RAM of the Sony Vaio PCG-81312L.

Written By: Erin Huene




INTRODUCTION

This repair is necessary if there is an issue with the RAM of your computer, therefore requiring replacement. Actions involved are taking out one main screw, removing the RAM, and tightening the screw back in place. This guide requires no special requirements or hazards.

TOOLS:

- Phillips #0 Screwdriver (1)

Step 1 — RAM



- Unscrew the cover and remove it.

Step 2



- Remove the RAM gently it from its place.

To reassemble your device, follow these instructions in reverse order.