Sony Xperia L2 LTE Battery Replacement

Replace a faulty battery to extend the life of your Sony Xperia L2 LTE.

Written By: Carrie Schmitt

This document was generated on 2020-04-15 10:58:21 PM (MST).

INTRODUCTION

This guide will take you step by step through the process of replacing your Sony Xperia L2 battery. This guide will help those who have a dead or faulty battery to extend the life of your phone. If your phone is overheating, not powering on, or not charging properly, replacing the battery may fix those problems.

## ⚙ TOOLS:

- T4 Torx Screwdriver (1)

Step 1 — Battery

⚠ Before disassembling the battery, power off your Sony Xperia L2 LTE.

● Remove SIM card tray.

Step 2

● Use the plastic opening tool to pry the back case of the phone off.

⚠ The fingerprint sensor is connected to the motherboard.

● Disconnect the fingerprint sensor.

Step 3

- Unscrew all 10 screws from the top and bottom portion of the phone using a T4 Torx screwdriver.

- Use the plastic opening tool to remove the unscrewed top and bottom portion of the phone.

This document was generated on 2020-04-15 10:58:21 PM (MST).

© iFixit — CC BY-NC-SA www.iFixit.com Page 4 of 5

Step 4

- Disconnect the battery cable from the motherboard.

- Pry up the battery and remove it from the device.

- (i) Battery may have adhesive that needs to be removed prior to removing the battery.

  ⚠ Be careful not to jab the battery with any sharp tools. A punctured battery may leak dangerous chemicals or catch fire.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-04-15 10:58:21 PM (MST).