



Sony ZS-RS60BT Repair Battery Replacement

This guide will show how to remove and replace the batteries.

Written By: Sarah Hamrin



INTRODUCTION

This guide will show how to replace batteries in the Sony ZS-RS60BT.



PARTS:

- "C" Batteries (6)

Step 1 — Battery



- Locate back panel.
- Put firm downward pressure on the panel until it slides off.

Step 2



 If the batteries are corroded, it is recommended to wear gloves when removing the batteries.

- From the positive side of the battery, push it to the negative side and lift up.
- Repeat for each battery until the compartment is empty.

To reassemble your device, follow these instructions in reverse order.