



# SteelSeries Arctis Pro Plus GameDAC Volume Control Knob Replacement

This guide will show you how to replace the volume control knob located on the SteelSeries Arctis Pro Plus GameDAC.

Written By: Kyle Chang



This document was generated on 2020-01-14 01:11:42 AM (MST).

## INTRODUCTION

If your volume control knob is no longer rotating properly, is damaged or needs cleaning, you may need to remove the knob. Follow this guide to safely access and remove the knob.

### TOOLS:

- [iFixit Opening Tools \(1\)](#)

## Step 1 — GameDAC Volume Control Knob



- Remove the plastic cover using the iFixit opening tool to pry the cover open.
- Insert opening picks to keep the cover open as you work your way around the GameDAC.
- Pop the cover off.

## Step 2



- Remove the control wheel from the GameDAC by pulling on the knob.

To reassemble your device, follow these instructions in reverse order.