



Sylvania SDVD9004 Back cover Removal

Prerequisite only This guide will show you how to take off the back cover of the Sylvania SDVD 9004.

Written By: Casey Glover



INTRODUCTION

To replace anything in the Sylvania SDVD 9004, the back cover needs to be removed. This guide will show you how.

This guide uses incorrect tools. Use an ESD safe tool, such as a nylon spudger, to complete the steps that deal with delicate internal components.

TOOLS:

- [Phillips #0 Screwdriver \(1\)](#)
- [Heavy-Duty Spudger \(1\)](#)

Step 1 — Back cover




- Remove ten 7mm Phillips #0 screws.
- Remove four 5mm Phillips #0 screws.

Step 2



- Flip the device over.
- Lift the top.

Step 3



⚠ This guide uses incorrect tools. Use an ESD safe tool, such as a nylon spudger, to complete this step.

To reassemble your device, follow these instructions in reverse order.