



System76 Serval WS Hard Drive Replacement

How to replace a System76 Serval WS hard drive.

Written By: Oliver Anderson



INTRODUCTION

This guide will show how to replace the hard drive inside your Systems76 Serval WS laptop.

TOOLS:

- Pro Tech Toolkit (1)

Step 1 — Hard Drive



- Remove the three screws attached to the back panel.
- Gently remove the back panel.

Step 2



- Remove the hard drive from the back.
- Remove the four screws that attach the protective plastic case on the drive.

 Save the protective plastic case as it can be placed on the new drive.

To reassemble your device, follow these instructions in reverse order.