



# TDK Life on Record Trek Max A34 Battery Replacement

Replacing the battery of your TDK Life on Record Trek Max A34.

Written By: Kayla



## INTRODUCTION

If your device will not turn on after charging then your battery is is most likely defective. If this is the case, your device will require a battery replacement.

### TOOLS:

- [Metal Spudger \(1\)](#)
- [T6 Torx Screwdriver \(1\)](#)

## Step 1 — Battery



- Flip your device upside down so the battery cover is facing upwards.
- Using the Torx T6 screwdriver, remove all seven 6 mm Torx screws that are located along the perimeter of the battery cover.

## Step 2




- Use the metal spudger prying tool to gently pry off the battery cover.
- The battery should now be exposed.

## Step 3



- Starting from where the wires are connected, gently pull the battery out of the device.

## Step 4



- Unplug the battery from the device by detaching the wires at the white connection box.

**i** Detaching the wires may require some force.

**!** Be careful not to rip the wires out of the device or the battery.

## Step 5



- The battery is now separated from the device and may be replaced with a new battery.

To reassemble your device, follow these instructions in reverse order.