




# Tagital T9X Speaker Replacement

Replace the speaker on the Tagital T9X tablet.

Written By: Adam Bamforth



## INTRODUCTION

Use this guide to replace the speaker in your Tagital T9X.

### TOOLS:

- [64 Bit Driver Kit \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Spudger \(1\)](#)
- [Tweezers \(1\)](#)

## Step 1 — Back Cover



- With the tablet turned off, remove the two 5mm Phillips head screws from the top of the tablet.


 These screws are extremely easy to lose. Be sure to store them in a safe place.

## Step 2




- Use a 1 cm wide plastic opening tool to remove the back panel. Go around the entire back panel to ensure safe removal.
- The power, return, and volume buttons are not firmly secured to the panel; it is likely they will fall off in the process of removing the panel.

## Step 3 — Speaker



- Detach speaker wires from motherboard.
- *i* The wires are fragile and may break off while handling them.

## Step 4



- Use the plastic spudger to remove speaker from the back panel.

To reassemble your device, follow these instructions in reverse order.