



Technostar Sandwich Toaster Thermal Fuse Replacement

This guide will show you how to replace a thermal fuse of a Technostar Sandwich Toaster.

Written By: charlottevisser63



INTRODUCTION

A toaster's fuse will often fail over time. This guide will show you how to fix your Technostar Sandwich Toaster.

TOOLS:

- Phillips #0 Screwdriver (1)
- Pincers (1)
- Spring Clamps (1)

PARTS:

- Thermal fuse 10A 250V Tf225C (1)

Step 1 — Thermal Fuse




- Open the toaster.
- Remove the four screws which attach the mold.

Step 2





- Remove the mold to get access to the heating coil.

Step 3



- Find the thermofuse.

Step 4



- Cut the two wires that connect to the thermal fuse.

Step 5



- Align the thermal fuse with the open wires.
- Put the spade connectors over the wires.
- Using pliers, clamp the wires together.

Step 6



- Replace the molds.
- Replace the four screws which attach the mold.

