



# Tegra Note 7 Disassembly

Peek inside of Tegra Note 7

Written By: Calvin Brice



 **TOOLS:**

- Essential Electronics Toolkit (1)

## Step 1 — Tegra Note 7 Disassembly



- Completely power down device.
- Remove stylus, sd card (if you have one), and case adaptor from device.
- Insert thin tool (I used a knife) into the seam around the edges of the device and gently pry back cover off. It is held on only by clips but will require carefulness to avoid damage.

To reassemble your device, follow these instructions in reverse order.