




The Sharper Image Literati Tablet Battery Replacement

This guide will walk you through the steps necessary to replace the battery of the Sharper Image Literati.

Written By: Spencer Dodder



This document was generated on 2019-09-21 07:12:53 AM (MST).

INTRODUCTION

The Sharper Image Literati Tablet may need a battery replacement years or months after purchase, according to reviews online. The battery replacement for The Sharper Image Tablet can be done in approximately 10 - 25 minutes with moderate difficulty level in seven steps. Battery replacement for The Sharper Image Literati Tablet may be the solution in fixing technological issues individuals encounter with the devise.

TOOLS:


- [Spudger](#) (1)
- [Soldering Iron](#) (1)
- [Hair Dryer](#) (1)
- [Plastic Cards](#) (1)

Step 1 — Battery



- Wedge plastic spudger tool between the back panel and the body of device.
- Pry apart the back panel and the device.

Step 2



- [Desolder](#) the battery wires from the circuit board.


Step 3



- Warm the battery with a hair dryer.

 Be carful not to over-heat the battery, this could cause the battery to ignite.

Step 4



- Gently wedge a spudger or thin plastic card between the battery and the body of device. Work the spudger or card along the length of the battery to free it from the adhesive.

 Do not bend or puncture the battery. Work slowly and carefully.