



Thinkpad T480, Disabling the Internal Battery

How to Disable the Internal Battery for the Thinkpad T480

Written By: Ethan Breckenridge

INTRODUCTION

When replacing something else in the computer, disabling the internal battery is an important step to make sure you don't

To reassemble your device, follow these instructions in reverse order.