



Toaster Lever Replacement

How to fix a toaster that won't stay down.

Written By: Sydtracked

INTRODUCTION

How to fix a toaster that won't stay down.

TOOLS:

- [Mahi Driver Kit - 48 Bit Driver Kit \(1\)](#)
- [Anti-Static Brush \(1\)](#)

To reassemble your device, follow these instructions in reverse order.