




# Toshiba Satellite 1415-S105 Upper Case Replacement

Prerequisite Only

Written By: Kiril Lange




# INTRODUCTION

Prerequisite Only

## TOOLS:



- Phillips #0 Screwdriver (1)

## Step 1 — Upper Case





- Disconnect both speaker connectors located near the center of the laptop.

## Step 2



- Unscrew all visible screws on the heat sink shield.

## Step 3




- Disconnect the monitor connector.

## Step 4



- Starting from the front right corner pry apart the black bottom from the gray top.

## Step 5



- Set aside the top half.

To reassemble your device, follow these instructions in reverse order.