




Toshiba Satellite A85-S107 15" Disc Drive Replacement

This guide will demonstrate how to install the disc drive.

Written By: Alana



INTRODUCTION

Use this guide to replace or install the disc drive in your Toshiba laptop.

TOOLS:

- **Phillips #0 Screwdriver** (1)
- **plastic openers**
- **iFixit Opening Tools** (1)

Step 1 — Battery



- Power off the laptop.
- ⚠ Disconnect the power cable from the laptop. If you do not, electric shock may result.


Step 2



- Flip the laptop over and orient it such that the battery faces towards you and the front faces away from you as shown in the diagram.
- Unlock the battery by sliding the tab shown to the right

 This tab will latch into place.

Step 3



- Slide the tab shown to the left and remain holding it.
- *(i)* This tab does not lock into place like in the first step.
- Place your thumb on the grips of the battery as shown.
- While holding onto the grips, pull the battery towards you and away from the laptop.

Step 4 — Disc Drive



- Flip the laptop over and orient it so that the battery faces away from you.
- Remove the 5mm Phillips #0 screw on the bottom case.

Step 5



- Insert the plastic opening tool into the gap between the disk drive and the laptop and pop out the disk drive.
- Slide the disc drive out of its slot on the left side of the computer. It should slide out easily.

To reassemble your device, follow these instructions in reverse order.