




Toshiba Satellite E45t-B4204 Trackpad Replacement

This guide will teach you how to replace a Toshiba Satellite E45t-B4204 trackpad.

Written By: Marvin Scott




INTRODUCTION

This simple guide will teach you how to replace a Toshiba Satellite E45t-B4204 trackpad. You will only need two different size bits to replace the trackpad. Make sure you ground yourself before opening the backing.

TOOLS:

- Phillips #0 Screwdriver (1)
- Phillips #1 Screwdriver (1)

Step 1 — Trackpad




- Remove 15 screws with the Phillips #1 screwdriver.

Step 2





- Remove Battery

Step 3




- Ground yourself.

Step 4




- Remove speaker screws.

Step 5



- Unplug and remove speakers.

Step 6




- Remove processor.

Step 7




- Remove heatsink.

Step 8



- Remove WiFi chip.

Step 9




- Remove keyboard screws.

Step 10



- Remove motherboard and attached components.

Step 11



- Remove trackpad.

To reassemble your device, follow these instructions in reverse order.