



# Toshiba Satellite L305D-S5895 Battery Replacement

This guide will show how to remove the battery properly from the laptop.

Written By: Daniel Matheson



## INTRODUCTION

This guide will show you how to change the Battery for the Toshiba Satellite L305D-S5895.



## PARTS:

- Toshiba PA3534U-1BRS Laptop Battery (1)

## Step 1 — Battery Replacement



- Make sure switch with the number 1 is moved to the right, in the unlocked position.

## Step 2



- Slide and hold switch number 2 to the left, and use your finger to pry battery out using the slot to the right of the switch.

## Step 3



- Remove the battery from the laptop.

To reassemble your device, follow these instructions in reverse order.