



Toshiba Satellite L305D-S5895 Hard Drive Replacement

This guide will show you how to remove and replace the hard drive in the laptop

Written By: Daniel Matheson



 **TOOLS:**

- Phillips #0 Screwdriver (1)

Step 1 — Hard Drive



- Locate these two screws that you will need to remove.
- Undo these two screws with the Phillips #0 Screwdriver.

Step 2



- Use your finger to lift and remove the cover to the Hard Drive.

Step 3



- Pull the black ribbon back and up to remove the Hard Drive.

Step 4



- Remove the cover to reveal the hard drive.

Step 5



- Pull out the hard drive using the ribbon attached to it.

To reassemble your device, follow these instructions in reverse order.