Toshiba Satellite L855-S5119 Optical Drive Replacement

We will replace a broken or faulty optical drive.

Written By: Tyler Shafer

This document was generated on 2019-10-17 02:47:27 AM (MST).

© iFixit — CC BY-NC-SA | www.iFixit.com | Page 1 of 4

INTRODUCTION

This guide will inform readers on how to replace the optical drive which may have stopped reading disks.

TOOLS:

- Phillips #0 Screwdriver (1)
- Phillips #1 Screwdriver (1)

PARTS:

- Toshiba Satellite L855 Optical Drive (1)

This document was generated on 2019-10-17 02:47:27 AM (MST).

Step 1 — Back Plate Removal

- Turn the laptop over to place it top down.

- Use a Phillips #1 screwdriver to remove the screw holding in the back plate. This screw does not come out of the plate.

- Lift the back plate off the laptop, exposing the RAM and Hard Disk.

Step 2 — Optical Drive

- Using a Phillips #0 screwdriver, remove the single 3mm screw.

This document was generated on 2019-10-17 02:47:27 AM (MST).

Step 3

- Rotate the laptop so that you have access to the optical drive.

- ⓘ The optical drive is now only attached by a port in the drive's back. The optical drive can be pulled straight out of its housing.

- Remove the drive.

To reassemble your device, follow these instructions in reverse order.