




Toshiba Satellite c650d Keyboard Replacement

This guide will provide steps for replacing the keyboard of a Toshiba Satellite C650D.

Written By: Brenna Callahan



INTRODUCTION

If the keyboard is not working, it may need to be replaced. This guide contains instructions for replacing the keyboard of the Toshiba Satellite C650D.

TOOLS:

- Phillips #0 Screwdriver (1)
- Anti-Static Wrist Strap (1)
- Magnetic Project Mat (1)
- Spudger (1)

PARTS:

- [Toshiba Satellite C650D Replacement Keyboard \(1\)](#)

Step 1 — Battery



- Unplug the laptop and turn it off.
- Flip the laptop upside down.
- Locate the battery on the underside of the laptop.

Step 2




- Push the two latches away from the battery.

Step 3



- Slide the battery away from the laptop.
- Locate the serial number on the battery to order a replacement.

Step 4 — Keyboard



- Remove the fourteen 6.0mm and two 2.0mm Philip's #0 screws connecting the keyboard to the back.
- *i* Make sure you keep track of all the screws.


Step 5



- Flip the computer over.
- Use a nylon spudger to lift the keyboard.
- Go around the edge of the keyboard and lift until the keyboard separates from the back.

i Only lift the keyboard a little at a time, otherwise you risk damaging the plastic.

Step 6



- Detach the ribbon cable that connects the keyboard to the motherboard.

To reassemble your device, follow these instructions in reverse order.