



Tristar Blender Disassembly

Tristar blender used for blending and mixing all kind of ingredients.

Written By: koen merkx



 **TOOLS:**

- Phillips #1 Screwdriver (1)

 **PARTS:**

- Housing (1)

Step 1 — Tristar Blender Disassembly




(i) The assembled mixer.

Step 2




- To disassemble the 3 parts you've got to disconnect the little ring. Use a screw driver to get the ring loose.

Step 3




- Unscrew 3 screws to open the casing.

Step 4



- Unscrew 4 screws to disassemble the printplate and 2 to unscrew the wiring. Then you can lift the motor out by hand.

Step 5



- To disassemble the motor holders you can slide them of the casing.

un-screw 3 screw froms the housing