



UE BOOM 2 D-ring Replacement

iFixit guide to remove and replace the D-ring on the UE Boom 2 Speaker

Written By: Alex Bahm



INTRODUCTION

The D-ring is located under a rubber cover on the bottom of the UE Boom 2 speaker. Replacing this part does not require the removal of any other components, and it will not void the device warranty.

TOOLS:

- Fingers (1)

Step 1 — D-Ring



- Locate D-ring on the bottom of the speaker.

Step 2



- Hold onto and lift up on the D-ring.
- Unscrew the D-ring by turning it counterclockwise.

To reassemble your device, follow these instructions in reverse order.