




Uniden D1685-3T Battery Pack Replacement

If your battery is dead or not charging, it may need replacing.

Written By: William Mullens



INTRODUCTION

The battery pack is what provides the phone power. It is important to have a battery that is charged so that it will not die during a phone conversation.

Step 1 — Battery Pack



- Turn the phone over with the back facing upwards.

Step 2



- Press your thumb down on the top of the cover and push downwards.

Step 3



- Once the back has been removed, the battery will be connected by 2 wires.
- ⚠️** Do not pull on the red and black wires.
- Pull the small, grey connector to disconnect the battery pack.

Step 4



- Take the replacement battery and push the grey connector back into the phone.

To reassemble your device, follow these instructions in reverse order.