



Uniden Dect 6.0 Battery Replacement

This guide will help a Uniden Dect 6.0 home phone owner replace the battery pack.

Written By: Mary



INTRODUCTION

This guide explains the simplest and quickest way to replace the faulty batteries on the back of the Uniden home phone!



PARTS:

- [Uniden Replacement Battery \(1\)](#)

Step 1 — Battery




- Locate the battery compartment on the back of the Uniden home phone.
- Place your finger on the groove, and pull directly back on the cover to gain access to the battery.

Step 2



- Remove the white battery pack from the battery compartment.

Step 3



- Remove the red and black wired port from the plug directly under the battery compartment.

To reassemble your device, follow these instructions in reverse order.