




Unnecto Drone M Back Case Replacement

This guide will provide you with a simple yet effective method for replacing the back case of the Unnecto Drone M.

Written By: Jordan Duran



 **TOOLS:**

- [Spudger \(1\)](#)

Step 1 — Back Case



- Place the phone face down in a cleared working area.
- Remove the back case by applying moderate force to the indentation in the lower left corner of the case.

Step 2



- Replace the old back case with the new one.
- Reassemble the phone by following the steps in reverse order.

To reassemble your device, follow these instructions in reverse order.