



VTech InnoTab 2 Battery Replacement

Replace dead batteries to restore power to VTech InnoTab 2.

Written By: Mark Lefcourt



INTRODUCTION

A quick guide on how to replace dead batteries for your VTech InnoTab 2. This device requires 4 AA batteries to run without an AC adaptor. No tools are required to complete this guide.



PARTS:

- 4 AA batteries (1)

Step 1 — Battery



- Apply slight pressure and slide the button above the battery cabinet to the right to open.
- Remove battery cabinet cover by sliding away from the center of device.

(i) This device requires 4AA batteries to function without the AC adaptor.

To reassemble your device, follow these instructions in reverse order.