



VTech InnoTab Max Cover Replacement

Cover replacement guide for the VTech InnoTab Max.

Written By: Alexander Bees



INTRODUCTION

This guide will show any user how to replace the cover on a VTech InnoTab Max.

TOOLS:

- [J1 Screwdriver Bit \(1\)](#)
- [iFixit Precision Bit Driver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Magnetic Project Mat \(1\)](#)

Step 1 — Cover



- Remove all screw caps from the back panel using a metal spudger.

Step 2



- Next remove all of the now uncovered screws.


(i) If there is a cartridge in the device make sure to remove it.

Step 3



- Now that all of the screws have been removed, pry the back cover off using a plastic opening tool.

Step 4



- Here you can see the back cover has been fully removed and you can now access the front cover.
- To remove the front cover, remove the springs holding the pictured brackets in place, then pull it away.

To reassemble your device, follow these instructions in reverse order.