



VTech Kidizoom Smartwatch DX2 Faceplate Replacement

Use this guide to replace the faceplate on your VTech Kidizoom Smartwatch DX2.

Written By: Jessica Richard



INTRODUCTION

If the faceplate to your watch is cracked or simply needs a clean, the following guide will show how to remove and replace this piece.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

Step 1 — Faceplate



- In order to remove the faceplate you must start by placing the watch screen upwards.

Step 2



- Use iFixit's opening tool, another similar tool, or simply use your fingernail to gently pry open the faceplate away from the screen starting from an edge.
- *(i)* You may hear a popping sound, but this is normal.

Step 3



- Once successful, pull the remaining faceplate off from the watch.

To reassemble your device, follow these instructions in reverse order.