




VTech Record and Learn KidiStudio Black Piano Keys Replacement

We will be replacing the black piano keys

Written By: Shaina Carbonel



INTRODUCTION

Showing how to replace the black piano keys on the VTech Record and Learn KidiStudio.


TOOLS:

- Phillips #2 Screwdriver (1)

PARTS:

- Replacement Black Piano Keys (1)


Step 1 — Black Piano Keys



- Unscrew 11 PH2 screws (7 mm).
- Remove the black plastic backing.


⚠ Remove the batteries from the toy before beginning replacement of the piano keys.

Step 2




- Near the bottom of the device, unscrew 5 PH2 screws (7 mm) on the electric board.
- Pull back the electrical board.

Step 3



- Unscrew 6 PH2 screws (11 mm) on the black bar holding the keys on the device.

Step 4



- Pull out the black piano keys and replace with the new piano key part.

To reassemble your device, follow these instructions in reverse order.