




# Vivitar Vivicam T027 Power Button Replacement

Replace the power button of the Vivitar Vivicam T027 digital camera.

Written By: Dana



## INTRODUCTION

If the power button on your Vivitar Vivicam T027 digital camera breaks or gets jammed, you may need to replace it. This guide will show you how.

Note: This repair requires soldering. View the [soldering guide](#) for more information.

### TOOLS:

- [Tweezers](#) (1)
- [Soldering Iron](#) (1)
- [Phillips #00 Screwdriver](#) (1)

## Step 1 — Power Button




- Using a Phillips #00 screwdriver, remove four exposed 3mm screws.
- You will find one screw on the top, one on the bottom, and one on each side of the camera.
- Put the screws in a safe place so you can find them and put them back in later.

## Step 2




- Remove the sticker on the top of the camera.
- Use the Phillips #00 screwdriver to remove the screw that was underneath the sticker.

## Step 3




- Separate the front and the back of the camera completely to expose the motherboard.

## Step 4



- Locate the power button on the top of the camera.
- Using tweezers, gently remove the black plastic cover from the power button.

## Step 5



- Using a soldering kit, de-solder the black and red wire from the silver power button.
- Solder the new power button to the black and red wire.

**⚠** To avoid burns, be careful of the heat from the soldering iron.

**ⓘ** Reference the [soldering guide](#) for assistance!

To reassemble your device, follow these instructions in reverse order.